

Titon FireSafe® Double Air Brick - Installation Guide

Installation

- Handle units with care ensuring no paint damage occurs on or around the grilles
- Install in accordance with the Residential Ventilation Association Good Practice Recommendations
- The ducting needs to be supported during install to ensure it slopes towards the outside as set out in the Domestic Ventilation Compliance Guide (DVCG)
- Connection of the metal air bricks to the metal adaptors/sleeves should be made using self-tapping screws suitable for an $\varnothing 4.5\text{mm}$ hole
- When metal air bricks are used with metal sleeves they must be fixed to the required length before installing into the fabric of the building
- The metal air brick/sleeve must be fire sealed to the inner wall

Rigid Ducting - Installation Methods Example

204x128 Air Bricks to 220x90 Ducting

